Engineering data

Number of axes	1	
Aux supply	24 ± 10%	V DC (0.6A)*
Power supply	0-400	V AC 3~
DC bus voltage	0-560	V DC
Input power (S1)	7.9	kVA
Rated output current	14	A (rms)
Peak current	30	A (rms)
Losses at rated load	110	W

** Without power supply for the servomotor holding brake and digital outputs.*

Supported motor feedbacks* 2x

Hiperface DSL

EnDat 2.2

BiSS-C

SSI

Hall effect sensors (using digital inputs)

** Support depending on servoamplifier firmware*

External encoder 1x

Incremental encoder input / emulation output*

** Support depending on servoamplifier firmware*

Recommended filter

NCZXX3P49-04

Mechanical data

Weight	2.3	kg
Protection	IP20	
Operating temperature	<-32; 40>	°C

Inputs / outputs

Isolated digital inputs	8x	0-24 V DC (0-10 V low, 13-24V high) 20mA
Digital inputs	3x	0-30 V DC (0-0.8 V low, 2.4-30V high) 20mA
Isolated digital outputs	6x	5-24 V DC 300mA / output
Analog input	1x	0-10V
Thermistor	2x	Standard PT1000

Functional safety

Safe torque off (STO) - 2 channels **SIL 3**

Supported communication*

1x Ethernet	EtherCAT
1x Ethernet	fast service protocol (FSP)
1x Ethernet	Modbus TCP / ProfiNET / service TCP or UDP
1x CAN	RAW CAN

** Support depending on servoamplifier firmware*

EtherCAT® Technology Group

CANopen over EtherCAT®

PROFINET INDUSTRIAL ETHERNET

Customs info

HS Code	85044087

Firmware feature support					
Feature	**Firmware**				
	Standard (EtherCAT)	**PROFINET**	**PROFIsafe**	**CANopen over EtherCAT (CoE)**	**TGZ+Motion***
EtherCAT (slave)	✓			✓	
EtherCAT (master)					✓
PROFINET (device)		✓	✓		✓
PROFIdrive		✓	✓		
PROFIsafe (device)			✓		
CANopen (slave)				✓	
RAW CAN	✓	✓			✓
CANopen over EtherCAT				✓	
Modbus TCP (server)					✓
Interpreted PLC	✓	✓	✓	✓	
TGMotion realtime PLC					✓
External encoder input	✓	✓		✓	✓
External encoder output emulation		✓		✓	

Every motor feedback requires its own specific firmware version. Only one feedback type can be used at a time (for all axes).

**Servoamplifier has to be ordered as a TGZ+Motion variant, otherwise TGZ+Motion firmware can't be loaded.*

Connectors & interfaces